

January 2018

## GROUT RESCUE PRE-TREATMENT TECHNICAL APPLICATION GUIDE

### DESCRIPTION

#### CLEAN & PREP FOR RECOLOUR

*Easily removes stubborn staining from wall & floor grout joints  
Suitable for use around plastic & enamel baths & showers  
Fast & effective*

**Universeal Pre-Treat Cleaner** is a fast effective cleaner & primer specially formulated to pre-treat and ready the grout joints for the application of **Grout Rescue Colour & Seal**. Suitable for use on wall & floor grout joints around non porous tiled surfaces.

### DIRECTIONS FOR USE

#### SHAKE WELL BEFORE USING.

1. Read label before using and follow personal protection guidance.
2. Spray the grout joint from approx 20-30cm away.
3. Leave to work for 2-3 mins, then agitate with a stiff brush or scouring pad and rinse with clean water.
4. Allow grout joints to completely dry before applying Grout Rescue Colour & Seal.

**Always test Universeal Grout Rescue Pre-Treatment on an inconspicuous area prior to use.**

**PLEASE NOTE:** Avoid splashes on to sensitive surfaces such as metal, wood or clothing.

### SUGGESTED FIRST AID PROCEDURES

**Eye contact:** immediately flush eyes with plenty of water for approximately 15 minutes. If irritation persists, seek medical attention. **Skin contact:** wash area in question with soap and water. If irritation persists, seek medical attention. **Inhalation:** Remove person to fresh air. If symptoms persist, seek medical attention. **Ingestion:** Harmful if swallowed; Do not induce vomiting, if nauseous drink 2-3 glasses of water. Seek medical attention immediately and show this container or label.

### STORAGE INFORMATION

Close nozzle after each use. Store out of direct sunlight, keep in original container only.

### COVERAGE

N/A

### PRECAUTIONS

#### KEEP OUT OF THE REACH OF CHILDREN & PETS

H314: Causes severe skin burns and eye damage. H290: May be corrosive to metals. H302+H312+H332: Harmful if swallowed, in contact with skin or if inhaled. H317: May cause an allergic skin reaction. H318: Causes serious eye damage. H335: May cause respiratory irritation. P264: Wash hands thoroughly after handling. P280: Wear eye protection. P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. P301+P330+P331: IF SWALLOWED: rinse mouth. Do NOT induce vomiting. P302+P350: IF ON SKIN: Gently wash with plenty of soap and water. P304+P341: IF INHALED: If breathing is difficult, remove victim to fresh air and keep at rest in a position comfortable for breathing. P333+P313: If skin irritation or rash occurs: Get medical advice/attention. P337+P313: If eye irritation persists: Get medical advice/attention.



**Product SDS sheet available to download from the Universeal website.**

This information is offered without guarantee. It is the user's responsibility to ascertain the suitability and safety of this product thus assuming all liability and risk thereof. In case of doubt, the product should be tried out in an inconspicuous area. In the event of failure, the manufacturer shall be obliged to replace such product proven defective.



### Usage Guidelines

Dwell Time	Applications/Coats	Application Method	Dilution
2-3 mins	1 application	Brush/Pad/Sponge	Undiluted